
SUNGROW
Clean power for all

The 3-phase Hybrid

SH5.0RT / SH6.0RT / SH8.0RT / SH10RT

INSTALLATION & COMMISSIONING WITH BYD BATTERY




WWW.SUNGROWPOWER.COM




INSTALLATION & COMMISSIONING WITH BYD BATTERY


1 CONNECT POWER CABLES




2 SECURE GROUNDING CONNECTION




3 CHECK CABLE POLARITY




4 ASSEMBLE SUNCLIX CONNECTOR




5 ATTACH COMMUNICATION CABLES




6 SWITCH ON BATTERY



7 SET UP BYD Be Connect



8 OPEN iSolarCloud



© 2021 Sungrow. All rights and changes reserved.