solaredge

Wireless Gateway
Wireless Repeater

for inverters with SetApp Configuration

V. 1.3

EN Quick Installation Guide
DE Schnellinstallationsanleitung
NL Snelle installatiegids
FR Guide d'installation rapide
IT Guida rapida all'installazione
ES Guía de Instalación Rápida

Apply label here

EN Additional Information
DE Zusätzliche Information
NL Extra informatie

Antenna installation guide
Installationsanleitung für die Antenne
Installatiehandleiding voor antenne
Guide d'installation de l'antenne
Guida all'installazione dell'antenna
Manual de instalación de la antena

https://www.solaredge.com/sites/default/files/se-wifi-zigbee-antenna-installation-guide-eng.PDF

FR Information additionnelle
IT Informazioni aggiuntive
ES Información adicional


Wireless Gateway installation guide - Complete
Installationsanleitung für das Wireless Gateway
Installatiehandleiding voor Wireless Gateway
Guide d'installation de la Wireless Gateway
Guida all'installazione del Wireless Gateway
Manual de instalación del Wireless Gateway


https://www.solaredge.com/sites/default/files/se-wireless-gateway-wireless-repeater-installation-guide.pdf

Discard this product according to local regulations or send it back to SolarEdge.
Entsorgen Sie dieses Produkt entsprechend den örtlichen Vorschriften oder senden Sie es zurück an SolarEdge.
Verwijder dit product in overeenstemming met de lokale regelgeving of stuur het terug naar SolarEdge.
Mettre ce produit au rebut conformément à la réglementation en vigueur ou renvoyer celui-ci à SolarEdge.
Smaltire questo prodotto in conformità alle normative locali o restituirlo a SolarEdge.
Deseche este producto según las normativas locales o devuélvalo a SolarEdge.

EN What's in the Package
DE Was ist im Paket enthalten
NL Wat zit er in het pakket


FR Contenu du package
IT Cosa c'è nel pacchetto
ES Qué hay en el paquete







EN System Setup
DE Systemkonfiguration
NL Systeemconfiguratie

FR Installation du système
IT Configurazione di sistema
ES Configuración del sistema











A

EN Remove Inverter Cover
DE Entfernen Sie die Wechselrichterabdeckung
NL Verwijder de kap van de omvormer


FR Retirez le capot de l'onduleur
IT Rimuovere il coperchio dell'inverter
ES Retirar la tapa del inversor

ELECTRICAL SHOCK HAZARD
GEFAHR VON STROMSCHLÄGEN
ELEKTRISCH SCHOKGEVAAR
RISQUE DE CHOC ÉLECTRIQUE
PERICOLO DI SCOSSE ELETTRICHE
PELIGRO DE DESCARGA ELÉCTRICA









About SolarEdge

SolarEdge is a global leader in smart energy technology. By deploying world-class engineering capabilities and a relentless focus on innovation, we create smart energy products and solutions that power our lives and drive future progress.

SolarEdge
@SolarEdgePV
@SolarEdgePV
SolarEdgePV
SolarEdge
info@solaredge.com


solaredge.com

© SolarEdge Technologies, Ltd.
All rights reserved.
Version: 1.3, Nov. 2020
Subject to change without notice.
MAN-01-00725-1.3

B

EN Install Antenna
DE Installieren Sie die Antenne
NL Antenne installeren


FR Installer l'antenne
IT Installa l'antenna
ES Instalar la Antena



C

EN Pair with Inverter
DE Mit Wechselrichter koppeln
NL Verbind met omvormer


FR Jumeler avec onduleur
IT Abbinare a Inverter
ES Conectar con el inversor



D

EN Connect Gateway and Repeater
DE Verbinden Sie Gateway und Repeater
NL Verbind Gateway en Repeater


FR Connecter la gateway et le répéteur
IT Collegare gateway e ripetitore
ES Conectar gateway y repetidor



E

EN Make Sure Blue LED Lights up Continuously
DE Stellen Sie sicher, dass die blaue LED aufleuchtet
NL Zorg ervoor dat de blauwe LED oplicht

FR Assurez-vous que la LED bleue s'allume
IT Accertarsi che il LED blu si accenda
ES Asegurarse de que se encienda el LED azul



LED Indications

Blue	Communication with Monitoring Platform OK
Blue Blinking	No communication with Monitoring Platform
Red	Error
OFF	No power

OK